VARYTEC

User's manual

LED Tube Remote

Table of content

1. Safety instructions 1
2. Controls and functions 1
3. Technical Data 2

1. Safety instructions

FOR SAFE AND EFFICIENT OPERATION

Be careful with heat and extreme temperatureAvoid exposing it

to direct rays of the sun or near a heating appliance.

Not put it in a temperature bellow 41°F /5°C, or exceeding 95°F /35°C.

Keep away from humidity, water and dust

Do not place the set in a location with high humidity or lots of dust.

Containers with water should not be placed on the set.

Keep away from sources of hum and noise

Such as transformer motor, tuner, TV set and amplifier.

To avoid placing on un-stable location

Select a level and stable location to avoid vibration

Do not use chemicals or volatile liquids for cleaning

Use a clean dry cloth to wipe off the dust, or a wet soft cloth for stubborn dirt.

If out of work, contact sales agency immediately

Any troubles arose, remove the power plug soon, and contact with an engineer for repairing,

do not open the cabinet by yourself, it might result a

danger of electric shock.

Take care with the power cable

Never pull the power cable to remove the plug from the receptacle, be sure

to hold the plug. When not using the player for an extended period of time

be sure to disconnect the plug from the receptacle.

VARYTEC

2. Controls and functions

1. Brightness/ Speed increase – This button will increase the brightness of the selected color or increase the speed of the strobe, flash or fade.
2. Brightness/Speed decrease – This button will decrease the brightness of the selected color or decrease the speed of the strobe, flash, fade, or smooth.
3. LEDs off – Turns the LEDs off
4. LEDs on – Turns the LED s on
5. Color selection – Select one of 16 colors remain static or strobe
6. Flash – This function makes the fixture to scroll trough the colors automatically. You can control the speed of the strobe using the speed increase and decrease buttons
7. Strobe – This function activates the strobe effect. You can only strobe one of the 15 colors + white. You can control the speed of the sroll using the speed increase and decrease buttons
8. Fade – This function makes the fixture fade in and fade out of the different colors automatically. You can control the speed of the fade using the speed increase and decrease buttons
9. Smooth (Color flow) – This function makes the fixture to scroll trough the colors automatically. You can control the speed of the strobe using the speed increase and decrease buttons

3. Technical Data

Power Supply	12VDC
LEDs	96 (32 red, 32 green, 32 blue)
Power consumption	6W
Weight	2lbs/1Kg
Dimensions	40” x 2” x 2”



Importeur:

B & K Braun GmbH

Industriestraße 1

D-76307 Karlsbad

www.bkbraun.com

info@bkbraun.com

RoHS COMPLIANT 2002/95/EC